# LANE DETECTION USING I.MX 8M


#### Contents


• Get to know the board- <a href="https://www.nxp.com/docs/en/quick-reference-guide/8MMINILPD4EVKBQSG.pdf">https://www.nxp.com/docs/en/quick-reference-guide/8MMINILPD4EVKBQSG.pdf</a>

• Setup of I.MX 8M Mini

Running python-Open CV code on I.MX 8M Mini

## I.MX 8M Mini





If the serial port is not recognized, download and install updated drivers as listed below

Open the terminal window(Tera Term), choose the COM port number that corresponds to the "Enhanced COM port" or the highest numbered port and apply the following configuration.

• Baud rate: 115200

Data bits: 8

Parity: None

• Flow control: None

### Boot Up Procedure (for MicroSD mode)


- I.MX8M Mini can be configured with Android, Linux or Windows Operating systems. In this Lab we will be using Linux Operating System.
- Download Linux Operating system for I.MX8M Mini EVK from:

#### Linux Releases

#### Linux Current Release


Release and	Build Sources	Supported Platforms/Binary Demo	Incremental
Documentation		Files	Releases
Linux 5.15.5_1.0.0  Release Date: Mar 2022  Documentation  I.MX Linux Release Notes  I.MX Linux User's Guide  I.MX Linux Reference Manual  I.MX Porting Guide  I.MX Yocto Project User's Guide  I.MX VPU API Reference Manual  I.MX Graphics User's Guide  I.MX Machine Learning User's Guide	See README Con instructions for each release.     AACPlus Codec     Verisilicon IDE	IMX 8M Plus EVK  IMX 8M Nano DDR3L EVK  IMX 8M Nano EVK  IMX 8M Nano EVK  IMX 8M Quad EVK  IMX 7ULP EVK  IMX 6UltraLife, IMX 6ULL, IMX 6ULZ, IMX 7Dual  IMX 6SLL EVK  IMX 6QuadPlus, IMX 6Quad, IMX 6DualPlus, IMX 6Dual, IMX 6DualLife, IMX 6Solo, IMX 6SoloX  IMX 8M EVKs boot image(SystemReady-IR certified)	SCFW Porting Kit 1.12.1  I.MX 8DXL EVK  I.MX 8QuadXPlus(C0) MEK  I.MX 8QuadMax MEK

 Download and install Balena Etcher to flash the micro SD card with Linux Operating System.



- After the Micro SD card is loaded with Linux OS.
- Insert the Micro SD card to the I.MX board.
- Confirm Boot Switches
- The boot switches should be set to boot from the Micro SD

BOOT Device	SW1101	SW1102
MicroSD/SDHC2	0110110010	0001101000



# Power up the board

#### Connect USB Debug Cable

Connect the micro—B end of a USB cable into debug port J1701. Connect the other end to the PC. Two UART connections will appear on the PC, one for M4 core, one for A53 core. The console print will output on "Enhanced COM port", which can be found in "Device Manager" of the PC

#### Connect HDMI Display

Connect the mini SAS cable to J801 on the EVK(MIPI DSI connector) and connect the other end to the J5 on the MIPI to HDMI accessory card. Connect an HDMI cable to J2(HDMI port) on the MIPI to HDMI accessory card and connect the other end to a HDMI display panel




#### Connect Mouse/Keyboard

Connect the mouse to J301 (USB type-C port1) through the USB type C to A adapter

Connect Ethernet Cable
 Connect the ethernet cable to ethernet port.

- Board Boot Up
- As the board boots up you will see 4 penguins appear in the upper left-hand corner of the Open Embedded, then the Linux desktop.
   Now the board is ready and you can run the code.

# Boot Up Video



# Running the Code in Linux Terminal

 Open the terminal and run the following command for running the lane detection code.

```
$mk dir project
$wget https://github.com/swsmenon/Autonomous-Project-2/archive/master.zip -P project
$cd project
$unzip master.zip
$cd Autonomous-Project-2
$mk dir detected
```

• To check if the directories have been created type command:

\$ ls

# Editing the code for adding the path of datasets

```
$ nano AutonomousProjectNew.py
```

This will enable you to edit the code and add the path of data frames to the code corresponding to the location where it is stored in the I.MX8 Mini board. (make sure to change the path wherever path location has been mentioned)

```
col_frames = os.listdir('/home/swsmenon@ads.iu.edu/Downloads/frames4/Autonomous-Project-2-main/frames/')
col_frames.sort(key=lambda f: int(re.sub('\D', '', f)))

# load frames
col_images=[]
for i in tqdm(col_frames):
    img = cv2.imread('/home/swsmenon@ads.iu.edu/Downloads/frames4/Autonomous-Project-2-main/frames/'+i)
    col_images.append(img)
```

• Run python code


\$ python3 AutonomousProjectNew.py

To check if the output has been stored in the detected folder


\$ gtk-play

• You can check the files and folders, go to detected folder and click on the images saved.


Folder section should appear as shown below:



#### Videos for reference







Thank You!